


DREMEL®

MODEL: 215



| ITEM NO. | PART NO. | DESCRIPTION | ITEM NO. | PART NO. | DESCRIPTION |
|----------|--|-------------------|----------|----------------------------|---------------------------|
| 1 | 2610915566 Deleted by Dremel | Housing | 24 | 2615294 035 | Cross Recessed Head Screw |
| 3 | 2610941201 | Armature | 30 | 2615294028 | Retaining Snap Ring |
| 4 | 2610912826 Deleted by Dremel | Switch | 650 | 2610930692 | Chuck Wrench |
| 5 | 2610915563 Deleted by Dremel | Power Supply Cord | 802 | 2615298792 | Field |

| | | | | | |
|----|------------------------------------|-----------------------|-----|----------------------------|------------------|
| 8 | 2610915563 Deleted by Dremel | Label | 810 | 2615298790 | Carbon Brush Set |
| 9 | 2610915564 Deleted by Dremel | Nameplate | 817 | 2615297356 | Armature Lock |
| 18 | 2610014582 | Nut (Also 2615297355) | 825 | 2610913683 | Sealing Cap |
| 19 | 480 | 1/8 Collet | | | |
| 22 | 2615297373 | Insulator | | | |
| 23 | 2 615 294 043 | Pickup Clip | | | |