


DREMEL®

MODEL: 780



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	2610912359 Deleted By Dremel	Housing	28	2610014582	Collet Nut
4	2610912360 Special Order Only	Printed Circuit Board	29	480	1/8 Collet
8	2610912372 Deleted By Dremel	Label	30	2610913684	Sealing Cap
9	2610912373 Deleted By Dremel	Nameplate	31	2603490017	Torx Oval Head Screw 3x10
22	2610912364 Special Order Only	Motor	650	2610930692	Wrench
24	2610912366 Deleted By Dremel	Button	652	2610913433 Deleted By Dremel	Battery Charger
27	2610913127 Deleted By Dremel	Battery	823	2610009839	Armature Lock
